



# Manuel Feeding, Wood Fired Boiler User Manual



**ÜNLÜSOY**

Isıtma Sistemleri Sanayi ve Ticaret A.Ş.  
Pancar Organize Sanayi Bölgesi, 2. Etap No:2, Torbalı - İZMİR/TURKEY  
Tel: +90 444 35 32, Fax: +90 232 469 2412  
[www.unmak.com](http://www.unmak.com)





## INDEX

---

|   |    |
|---|----|
| INDEX.....                                      | 2  |
| INTRODUCTION .....                              | 3  |
| SHIPPING AND TRANSPORTATION .....               | 3  |
| SELECTION OF INSTALLATION PLACE .....           | 4  |
| SAFETY PRECAUTIONS.....                         | 6  |
| ELECTRICAL INSTALLATION INSTRUCTIONS.....       | 7  |
| BOILER FEATURES.....                            | 8  |
| RULES FOR HEATING INSTALLATION .....            | 9  |
| USAGE AND INSTALLATION OF DRAFT REGULATOR ..... | 12 |
| START-UP .....                                  | 13 |
| INFORMATION ON COMBUSTION.....                  | 13 |
| MAINTENANCE AND BOILER CLEANING.....            | 15 |
| INFORMATION ON USAGE ERRORS.....                | 16 |

KK-24EN Rev: 241231

---

This booklet covers below models:

**ÜKY/W**

25-35-45-60

---

## INTRODUCTION

---



We would like to thank you for your choice of ÜNMAK manual feeding solid fuel boilers. Please read the user manual carefully before installing and operating your product and keep the user manual for the duration of the product use. Do not touch or mix any part of the product except where permitted in the user manual. The installation, maintenance and service of the boiler requires a specialist technical team.

These operating instructions and regulations should be considered for the installation of the boiler, selection of the location for installation, installation of the boiler water installation and the design of the chimney.

ÜNMAK boilers are high-efficiency, steel-based hot water boilers designed to burn only solid fuel. These boilers are only used for heating of central heating, not suitable for direct use of water. However, it can produce hot water with the help of a water heater or heat exchanger. The energy required for domestic water will be taken from the boiler's energy.

ÜNMAK boilers convert the chemical energy of the fuel into heat energy by burning and load it onto the water which is the heating fluid. Excessive fuel overcharging to the combustion chamber will cause energy loss and will take longer to burn.



***User manual should be read carefully and stored with the associated warranty certificate for the life of the boiler.***

## SHIPPING AND TRANSPORTATION

---

ÜNMAK solid fuel boilers are manufactured from thick sheet. Boilers are sent in a complete package.

1. Boiler Group: It is shipped with boiler insulation and outer jacket covered.
2. Accessories: Draft regulator and its chain situated in ash box.

### **Safe transport of the product**

Solid fuel boilers are heavy products, so care should be taken when transporting the boiler to the place where it will be installed. The equipment used to lift and transport the product must therefore be of sufficient capacity.

---

---



In order to prevent damage to the boiler's outer plates and the boiler during transportation;


It is also convenient to remove the large grates from the forklift stands or the transport ring on the boiler. If the connection ropes are to be passed under the boiler when lifting by crane, preventive action should be taken to prevent the top of the boiler from being crushed by the ropes. The boiler standing on the floor should be taken by the crane should not be pulled. When transporting in cold weather, the boiler should not be lifted suddenly in case of freezing of the rope from the cold.



***When removing the packaging around the boiler, hard and sharp objects should not be used to prevent damage to the painted boiler plates under the packaging.***

## SELECTION OF INSTALLATION PLACE

The space where the boiler is installed must have sufficient free space for the installation, combustion and maintenance of the boiler. It must be spaced from the wall for service needs. For this purpose, the dimensions in the paragraph titled "Installation location dimensions" must be applied.



There should also be sufficient air circulation for efficient combustion, the chimney design must meet the required draft values for the model used and comply with the construction criteria given in the manual. The boiler should never be installed in open spaces, balconies, living areas (kitchen, living room, bathroom, and bedroom), explosive and flammable materials.

It is recommended to have a threshold of at least 10 cm in the doors opening into the building from the boiler room. If it is possible to illuminate the boiler room naturally, it should be ensured that the lighting openings do not come under the other windows of the building. If artificial lighting is done, a system that does not dazzle but illuminates the apartment must be properly installed. The main switchgear and panels for the boiler room should be placed around the entrance door and should be of leak-proof type. There should be a fire tube in the boiler rooms.

The boiler room must have at least 1 piece 6 kg dry powder dry fire extinguisher and at least 1 fire cabinet in large boiler rooms.

If natural gas or liquid fuel boilers are also used in the same boiler room, a tear surface must be designed.

The installed space must be directly connected to the external environment, allowing the access of fresh air. One of the grilles should be at most 40 cm below the ceiling of the boiler room and the other should be at least 50 cm above the floor. These grilles should be open continuously. The lower vent should be at least 40 x 40 cm and the upper grille should be at least 30 x 30 cm. Pets should not be fed, smoke and any food and beverages that may be affected should not be stored in the boiler room (boiler room).

All electrical and water installations must be carried out by authorized plumbers, in accordance with all applicable legal and technical rules and regulations.


The fuels to be burned in the boiler should be kept at a distance of at least 800 mm. It is recommended to store fuels in a separate space.

Boilers must be installed on a concrete base 10 cm above the base to protect the solid fuel from the moisture of the water. Laying of tiles with tile and tile stones facilitates cleaning.



***It is inconvenient to have flammable, caustic and flammable materials in the boiler room.***

#### Mounting dimensions:




The boiler room must be of a size to provide the minimum dimensions given in the picture below. When the boiler is placed, sufficient distance must be left to ensure that the service is comfortable.

Dimension A: 60 cm greater than the opening of the boiler door;  
If the above measurements are observed, a minimum of 8 m<sup>3</sup> of volume requirement in the regulations is ensured.

## SAFETY PRECAUTIONS

The boiler must be connected to a chimney in accordance with the specifications specified in the operating instructions and the relevant regulations. The chimney must provide the draft value required by the connected boiler. Your boiler should not be operated without a chimney connection and there must be enough draft to burn. In chimneys where sufficient draft is not ensured, the boiler must never be operated. Any installation in the place where the boiler is installed should not be installed.

In case of boiler changing in the boiler room, the old boiler must be removed or disconnected from the chimney and the insulation must be sealed and insulation should be made. In no case should more than one boiler be connected to the same chimney. The cylindrical chimney can be passed through the chimney in the figure.



Smoke chimneys should not be placed on the outer wall of the building unless it is a technical requirement. The wall thickness of the chimney walls should not be less than a brick thickness. For chimney construction, hollow bricks and briquettes should never be used. It should be plastered inside and outside of the rectangular chimney.

It should be ensured that fresh air is continuously introduced into the area where the boiler is installed. Reference must be made to the dimensions specified in this manual. The boiler should never be installed in living spaces or in a place directly connected to such a place. In order to reduce the risk of scaling and corrosion in old and new installations, the instructions given in the relevant section of this manual should be applied by the installer who installs the boiler. In particular, if the boiler is connected to an old installation, it is necessary to clean the waste completely before installation. The installation must be cleaned and cleaned several times.

Avoid overloading fuel into the boiler and check the suitability of combustion frequently. For any reason, direct cold water should not be added to the overheated boiler for cooling. This can cause noise in the installation, excessive thermal stresses in the boiler and thus permanent damage. The water in the installation must not be drained unless there is a risk of maintenance or freezing. The system design should ensure that the ratio between the water flow rate and the boiler capacity is not exceeded and the difference between the boiler inlet and outlet water temperatures of 20°C is not

exceeded. In order to minimize the water missing in the installation, the water level should be checked regularly and the leaks in the system should be removed. Because excessive water additions to the system will cause lime accumulation on the water side of the boiler and this will cause regional overheating and this will damage the boiler.

The boiler must not be burned directly, it must be installed on a level surface. It is recommended that the height of the base on which the boiler is to be installed shall be at least 10 cm and its width is wider than the outside dimensions of the boiler. Thanks to the base, the boiler is protected from the water that can accumulate on the ground.

The fire should not be approached when the lid of the burning boiler is open;



***Do not add water when the boiler is hot.***

## **ELECTRICAL INSTALLATION INSTRUCTIONS**

---

There is no electrical connection in wood type boilers. If the heating installation is built upwards, it can be used without a pump. In general, the circulation pump is used because the installation pipes are various up and down. Since there is no control panel in ÜKY / W type boilers, the operation of the pump depends on the user.



***If a direct power plug will be used for the pump, plug in the pump when the boiler temperature is 40°C.***




***Make sure that there is no adverse situation such as deformation in the pump plug and aging in the insulation.***

---


---



## BOILER FEATURES



| Model: ÜKY/W                      |                 | 18              | 25              | 35              | 45              | 60              |
|-----------------------------------|-----------------|-----------------|-----------------|-----------------|-----------------|-----------------|
| Fuel Type                         |                 | Log Wood        |                 |                 |                 |                 |
| Power (Coal)                      | kW              | 16-18           | 23-25           | 32-35           | 42-45           | 57-60           |
|                                   | kcal/h          | 14,630 - 15,500 | 19,780 - 21,500 | 27,250 - 30,100 | 36,120 - 38,700 | 49,020 - 51,600 |
| Power (Wood)                      | kW              | 14-15           | 20 - 22         | 27 - 30         | 34 - 37         | 49 - 52         |
|                                   | kcal/h          | 12,048 - 12,900 | 17,200 - 18,920 | 23,220 - 25,800 | 29,240 - 31,820 | 42,140 - 44,720 |
| Combustion Chamber Height         | mm              | 295             | 395             |                 | 450             |                 |
| Combustion Chamber Width          | mm              | 355             |                 | 500             |                 |                 |
| Combustion Chamber Depth          | mm              | 400             |                 | 450             | 500             | 600             |
| Combustion Chamber Volume         | dm <sup>3</sup> | 41,9            | 56,1            | 88,9            | 112,5           | 135             |
| Combustion Chamber Dimensions     | mm              | 355*180         |                 | 500*180         |                 |                 |
| Combustion Chamber Wall Thickness | mm              | 4               |                 |                 |                 |                 |
| Water Volume                      | lt              | 45              | 55              | 70              | 80              | 100             |
| Boiler Weight                     | kg              | 155             | 176             | 218             | 252             | 295             |
| Required Draft                    | mbar            | 0,15 - 0,20     |                 |                 | 0,20 - 0,30     | 0,25 - 0,35     |
| Temperature Control Range         | °C              | 40 - 90         |                 |                 |                 |                 |
| Recommended Return Temperature    | °C              | 40              |                 |                 |                 |                 |
| Max. Operating Pressure           | bar             | 3               |                 |                 |                 |                 |
| Test Pressure                     | bar             | 5               |                 |                 |                 |                 |
| Width (a)                         | mm              | 500             |                 | 600             |                 |                 |
| Depth (b)                         | mm              | 595             |                 | 650             | 750             | 850             |
| Flue Connection Height (d)        | mm              | 1100            | 1200            |                 |                 |                 |
| Total Boiler Height (h)           | mm              | 1210            | 1310            |                 |                 |                 |
| Flue Connection Diameter          | mm              | 130             |                 |                 | 160             |                 |
| Min-Max Flue Temperature          | °C              | 170-210         |                 |                 |                 |                 |
| Boiler Return/Flow                | R"              | 1 1/4"          |                 |                 | 1 1/2"          |                 |
| Boiler Filling/Discharging        | R"              | 1/2"            |                 |                 |                 |                 |




## RULES FOR HEATING INSTALLATION

Pay attention to the figure on the right while positioning the pump. When assembled, the junction box with the electrical terminals of the pump should not come down. The rotor part of the pump should not be pointing down.

When the circulation pump is installed, the failure of the electrical connections to come down will eliminate the problem of entering the water into the pump.

Perpendicular installation of the shaft should also be avoided in order to prevent the pump shaft from pressing the housing or the outer cover during operation.



### **Expansion tank:**

In hot water heating systems, when the water is heated from 10°C to 90°C, its volume increases by 3.55% in its first volume. Expansion tanks are used in order to obtain this expansion due to the temperature in the water. Expansion tanks also fulfill the safety of the system, that is, the pressure does not rise, and the necessary water support functions for the system.

### **Open expansion tanks:**

At the top of the system, the roof is put on the level difference and works open to the atmosphere. An expansion tank is placed at a slightly higher point than the highest point of the dispensing system to

collect the expanded water volume. The water that expands in the boiler is stored in the expansion tank by means of a travel safety pipe. When the water in the installation cools, the water of the installation is completed by the expansion tank by means of the return safety pipe. As the expansion tank also opens the system to the atmosphere, it ensures the safety of the system by preventing the pressure in the heating installation to rise above atmospheric pressure. The venting pipes are opened from the expansion tank to the atmosphere and the air in the system is discharged. It is recommended to use separate expansion tanks according to their capacities for each boiler in the installation. That is, it is not correct to connect the two boilers to a single expansion tank. There are return and return safety pipes for each boiler and expansion tank. Valves, check valves etc. on these safety pipes. No fittings such as material should not be installed. Safety pipes must reach the nearest point of the boiler inlet and outlet by the shortest vertical path. Horizontal movement is only allowed at the level of the expansion tank and at minimum length.

*Expansion tank volumes that must be rated according to the rated boiler capacity*

| <b>Boiler Power (kW)</b> | <b>Open Expansion Volume (lt)</b> |
|--------------------------|-----------------------------------|
| <b>25</b>                | 50                                |
| <b>35</b>                | 50                                |
| <b>45</b>                | 90                                |
| <b>60</b>                | 90                                |

*Open expansion tanks were selected by considering the open expansion volumes of Ünmak brand and panel radiator in the system.*

ÜKY/W boilers must be connected to an installation with an open expansion tank in accordance with the installation diagram shown below. The circulation pump can be connected to the return or return line. If the pump is in the boiler return; the open expansion tank must be higher than the discharge head of the pump.

#### **Warning about the water level:**

After the first water is pressed into the system, the minimum water level must be marked on the hydrometer. Water level should be checked on a daily basis and water should be added to the installation when it falls below the minimum value.




***Adding fresh water to the installation should only be carried out when the installation is cold.***

**Warning of corrosion in installation:**

ÜNMAK boilers are extremely resistant to corrosion. However, all iron-based components in the heating installation (including installation pipes and radiators) must be protected against corrosion. Oxygen in the heating water causes oxidation of the iron surfaces resulting in rust and thus loss of material.

During the initial filling of the installation, the accumulated air must be evacuated. Usually, if the necessary measures are taken after the first filling, there is no damage caused by the oxygen in the water. Oxidation is mostly caused by oxygen which is involved in the heating water during operation.

**Warning against frost protection:**

The heating installation must be completely isolated. Outdoor parts of the installation should be isolated more than the interior. If operating with an open expansion tank, the return and return pipes to the expansion line must be isolated or even the expansion tank must be isolated.

**Considerations in new installations:**

To minimize the addition of fresh water system design and sizing should be done correctly. None of the materials used in the installation must have a gas permeability. A maximum of 50 micron filters of synthetic or metal porous must be placed on the fresh water splicing line.

**Considerations for heating connected to old installations:**

A long-term heating system produces a protective layer (black magnetite) on metal surfaces in contact with water. When a new boiler is installed in the old system, the clean surfaces of the boiler will be the first place to start corrosion. Therefore, when a new boiler is connected to the old heating system, in addition to the measures to be taken for new systems, the following issues should be considered:

1. The old system must be thoroughly rinsed to remove any impurities and sediments from the boiler before connecting.
2. A manual valve air separator must be installed at the top of the system.

**!** *Before installing a new boiler in the old heating installation, the installation must be washed several times with water.*

**!** *The chimney must be cleaned before installation into the old chimney installations.*

**!** *Each boiler chimney must be detached. Never connect more than one boiler to the same flue system.*

## USAGE AND INSTALLATION OF DRAFT REGULATOR

---



To apply the regulator, apply several turns of teflon tape to the threads and screw the control into the the tapping securely but not too tightly as the threads may be damaged if the control is turned too far. Carefully insert the arm into the hole from right to left, with the arm in the horizontal position, lifting and loosening the hexagonal head screw if necessary.

Insert the arm about 75 mm, so that the chain, when attached, will not interfere with the opening of the firing door. The screw must bear on a flat segment of the arm, not on an edge. Attach end of onto the arm, keeping the arm in a relative the tighten the screw attach the other end after the ring is attached to the arm of the the chain with the ring and the hook to the arm of the regulator.

The chain to the hole in the air flap of the ash door. Regulator, all adjustments of the regulator should be made with the hook in this ring in this way, the chain can be unhooked (thereby closing the draft flap) when fueling the boiler is undesirable close the flap by turning the knob when fueling the boiler, as it cause to unnecessary wear on the regulator.

## START-UP

The following steps should be followed for the initial start of the boiler:


- Check for any visible glitches in the installation. If there is an error, please refer to the "Information on Usage Errors" page and correct the malfunctions.
- Observe that the hydrometer shows the water height and there is 1-2 meters of water according to the scale
- Open the middle cover and load fuel into the boiler.
- Open the lower cover to ignite the fuel. Do not use flammable substances to ignite.
- Close the bottom cover and turn the draft regulator by hand and adjust at 60-70 °C.
- You may add fuel after the fuel you add for ignition is completely ignited.
- You can use the secondary air hole in the middle as needed.




**Do not use flammable substances to ignite.**

## INFORMATION ON COMBUSTION

In order to ensure correct combustion, as a general rule, the air supplied to the fuel must be at a certain rate. The air required for a certain amount of fuel should not be too much. If the amount of air which is changed depending on the type of fuel is less than the required amount of carbon monoxide, the energy produced is reduced, the combustion starts, the combustion efficiency decreases, the air quantity is decreasing, the carbon monoxide decreases while the non-combustion air is heated from the chimney by heating in the furnace, the combustion is deteriorated and the combustion efficiency It decreases.



If the temperature of the flue gas is above the accepted values, excess energy will be ejected from the flue to the atmosphere. The material, the way of construction and the connection of the chimneys are important in terms of high combustion efficiency, low heating cost and protection of the environment.



The chimney must be good for burning to be good. It is recommended to use a high temperature resistant firebrick and stainless steel chimneys. The horizontal smoke ducts should be connected to the

chimney with a slope of at least 5% and the length should never exceed 1/4 of the height of the chimney. The height of the chimney should be well determined. The chimney sections must be circular unless necessary.

Never use a hollow brick on the chimney walls. The most ideal is the creation of fire bricks.


ÜNMAK boilers must be connected to an independent chimney that can provide the minimum desired minimum traction. Minimum traction is usually min. It should be measured with a manometer in 20 Pa. The part of the waste gas line between the boiler and the chimney should be insulated with glass wool. The waste gas pipe and flue pipe shall be made of steel sheet or material which is resistant to 400 oC. All connections on the exhaust gas pipe must be sealed to obtain better combustion and efficiency. The waste gas pipe must be connected to the chimney in the shortest way within the dimensions given in the diagram below. Horizontal connections and equipment such as elbows should be avoided.

A vertical steel pipe should not be used as a chimney, the chimney must have an inside and an outer surface. The outer surface may be steel or brick braided. For the inner surface of the chimney, corrosion-resistant stainless steel may be preferred. In order to prevent condensation, thermal insulation should be applied to the space between the inner and outer surfaces of the chimney.


At the lowest level of the chimney, there must be a cleaning lid made of steel that is sealed.

The length of the exhaust gas pipe between the chimney and the boiler must not exceed a quarter of the height of the chimney.

The size of the waste gas pipe and the chimney should be greater than the size of the waste gas outlet (fumes) of the boiler. The boiler chimney installed must be at least 1 meter above the roof of the space and at least 0.4 meter above the tiled roofs.



Chimney without chimney head and chimney head



Correctly installed chimney and chimney head with incorrectly installed chimney



**Excess air causes high flue temperature, high flue temperature also causes combustion in combustion efficiency.**

## MAINTENANCE AND BOILER CLEANING

For your system to work efficiently, regular maintenance is required by specialist teams according to the manufacturer's instructions.

### Regular checks:

- The water level should always be checked. The hydrometer (water level indicator) should be marked after the first filling of the system. If water level or pressure drops below the static pressure or system setting, water addition (boiler cold) must be done to the system. To protect the system and the boiler from corrosion, the water to be fed into the system needs to be softened according to local settings.
- Check that the front doors are closed properly, and if necessary, the door wickets should be replaced.
- Check that there is a gas leak from the chimney connection. If there is a leak, it must be repaired.
- Boiler heating surfaces should be checked. The formation of the corporation depends on the type of fuel used and the amount of combustion air. If it is understood that the outlet water temperature can not rise to the usual values in usual conditions, the boiler surfaces are treated, the heat transfer surfaces of the boiler should be cleaned.

### Boiler cleaning:

It should be done when the boiler is cold.

### To clear the boiler:

- Clean between the water jackets with the help of a spatula.
- Bitumen on the walls of the boiler forms a layer, which will prevent the energy that is released in the boiler from passing through the water, thus resulting in low efficiency. To prevent this, all heating surfaces should be cleaned regularly with the help of a spatula or as required.
- Boiler outer cover sheets can be cleaned as needed.

### Maintenance:

The system has a contracted service before each working season; We strongly advise you to call our authorized service to check the boiler, fittings, electrical connections, syringe. Never do maintenance work without the help of an expert.



***Chimney cleaning should be done by a firm that has successfully passed certification training in your city organized by the fire department chairs.***



## INFORMATION ON USAGE ERRORS

| PROBLEM                                       | CAUSE  | SOLUTION  |
|---|--|---|
| Insufficient heating                          | <ul style="list-style-type: none"> <li>Boiler heat transfer surfaces may be coated with soot and soot</li> <li>The fuel used may be of poor quality</li> <li>Pump may not be working</li> <li>Isolation failure</li> <li>Overloading the boiler</li> </ul> | <ul style="list-style-type: none"> <li>Clean with a spatula. (the boiler should not burn)</li> <li>Change the fuel and take some fuel before you buy it.</li> <li>Call for service, make sure the control panel's plug is plugged in.</li> <li>Increase the heat insulation of the room where the boiler is installed</li> <li>Load with padding, do not cover all walls of the boiler</li> </ul> |
| The bad side is not good                      | <ul style="list-style-type: none"> <li>Less combustion air</li> <li>Lack of chimney traction</li> </ul>  | <ul style="list-style-type: none"> <li>Make sure the air damper is open</li> <li>Check that there are no holes or cracks in any part of the boiler. If it is not enough yet, consult your abdomen.</li> <li>Have your chimney isolated.</li> </ul>  |
| The appearance of bitumen in smoke pipes      | <ul style="list-style-type: none"> <li>Incineration of plastic derived fuels in the boiler</li> <li>The boiler is not warmed</li> </ul>  | <ul style="list-style-type: none"> <li>Never burn plastic debris in the boiler.</li> <li>Check that there are no holes or cracks in any part of the boiler. If it is not enough yet, consult your abdomen. Have your chest isolated.</li> </ul>   |
| Excess fuel consumption                       | <ul style="list-style-type: none"> <li>Poor quality fuel</li> <li>High chimney draft</li> <li>Excess air</li> <li>Insufficient space insulation</li> </ul>   | <ul style="list-style-type: none"> <li>Change your fuel</li> <li>Check that there are no holes or cracks in any part of the boiler. If it is not enough yet, consult your abdomen.</li> <li>Reduce the draft regulator.</li> <li>Increase the heat insulation of the room where the boiler is installed</li> </ul>  |
| Smoke gas leakage from the boiler front doors | <ul style="list-style-type: none"> <li>Wear of cover wicks</li> <li>Deformation of covers</li> </ul>   | <ul style="list-style-type: none"> <li>Change wicks.</li> <li>Ensure that the burner does not rest on the covers. Get help from authorized service centers for deformed covers.</li> </ul>  |
| The boiler can not reach the set temp.        | <ul style="list-style-type: none"> <li>The temperature may have come out of the sensor housing</li> <li>The control panel may not be receiving power</li> <li>Fuel may be low</li> </ul>   | <ul style="list-style-type: none"> <li>Replace the temperature sensor end of the control panel card by lifting the boiler top cover. Pour heat transfer oil into the housing.</li> <li>Connect the plug of the control panel to the power supply. If it still does not work, call the service.</li> <li>Perform fuel loading</li> </ul>   |
| Heating of the expansion tank                 | <ul style="list-style-type: none"> <li>Expansion tank is under pump effect</li> </ul>  | <ul style="list-style-type: none"> <li>Increase the expansion tank further or reduce the cycle of the pump.</li> </ul>  |

| PROBLEM                                     | CAUSE   | SOLUTION   |
|---|---|--|
| Partial heating of the radiators            | <ul style="list-style-type: none"> <li>• Radyatör içinde hava olması</li> <li>• Pompanın yetersiz kalıyor ya da düşük kademede çalışıyor olabilir</li> </ul>  | <ul style="list-style-type: none"> <li>• Air in the radiator</li> <li>• The pump is running low or may be running low</li> </ul>   |
| Noisy water coming from the boiler          | <ul style="list-style-type: none"> <li>• Air stays inside before the boiler is first filled</li> </ul>  | <ul style="list-style-type: none"> <li>• See the start up section.</li> </ul>  |
| Panel writes Ht1 error (Fuel is over)       | <ul style="list-style-type: none"> <li>• The fuel in the boiler is exhausted</li> </ul>   | <ul style="list-style-type: none"> <li>• Add fuel to the winner</li> </ul>   |
| Panel writes Ht2 error (Temperature sensor) | <ul style="list-style-type: none"> <li>• The temperature sensor is not installed or may be removed</li> <li>• The temperature sensor may be faulty</li> </ul> | <ul style="list-style-type: none"> <li>• Fit the heat sensor firmly</li> <li>• Call a service</li> </ul>   |
| Panel writes Ht3 error (Limit thermostat)   | <ul style="list-style-type: none"> <li>• Limit thermostat may be thrown</li> </ul>  | <ul style="list-style-type: none"> <li>• Wear by turning the black plastic cover on the back of the control panel. Limit thermostat is activated by pressing the red pin.</li> </ul> |



***Do not open the boiler flaps at power cuts, do not water boiler in the boiler.***





**ÜNLÜSOY ISITMA SİSTEMLERİ SANAYİ ve TİCARET A.Ş.**

Address: Pancar Organize Sanayi Bölgesi, 2. Etap No:2, Torbalı – İZMİR/TURKEY

Tel: +90 444 35 32, Fax: +90 232 469 2412

[www.unmak.com](http://www.unmak.com)

---

---